

SUDBURY

TAYLOR RENTAL

712 Boston Post Road, Route 20
Sudbury, MA 01776

(978) 443-7368 1-800-56-4 RENT (7368) (508) 485-2299

Fax: (978) 443-0072

Monday to Thursday 8 AM - 5 PM, Friday & Saturday 8 AM – 5:30 PM

www.sudburytaylor.com

WHITE VINYL ARCHWAY SET-UP

1. Lay the 2 arch pieces on the ground, on edge, facing each other. Remove the 2 wing nuts & fasten the top of arch together & tighten wing nuts.
2. One of the pieces is labeled “Front.” Stand unit up and rotate accordingly.
3. There are 2 legs on each end of the arch, they are folded up. Remove wing nut, take bracket off of the bolt and push down so it forms a triangle. There’s another bolt below the first one to re-attach the leg to. Attach the wing nut. Repeat for all 4 legs.
4. Lay the front pieces on the ground in front of the archway facing each other.
5. Remove the 2 wing nuts and attach the 2 pieces together, tighten wing nuts.
6. Stand up the front piece and put the lower edge of the front piece under the lower edge of the rear piece. This may force the front edge of the rear piece up off the ground a little.
7. Use 4 cable ties to hold the front piece to the rear piece.
8. If using outdoors on a windy day it would be advisable to place sand bags on the leg supports.